

FIG. 1




FIG. 2

<u>100</u>






FIG. 5






FIG. 6




FIG. 11

1						
DISCONNECTION JUDGING CONDITIONS	DETECTION MODE					
	INTERVAL (TJ) DETECTION DETECTI MODE MODE MAINTENANCE TIME (Tm)					
	INTERVAL (Tj)					
	DETECTIONISSUE NUMBER- SMODE OF-TIMES OF IN CONNECTION REQUEST (m)					
	DETECTION					
ON JUDGING CONDITIONS	DETECTION DETEC L (TI)NUMBER-OF-TIMESMODE MAINTENANCE TIME (Tn)					
	NTERVA					
	ISSUE NUMBER- OF-TIMES OF INQUIRY (n)					
FRIENDLY NAME		TERMINAL A	TERMINAL B	TERMINAL C	XXXX SETUP DEFAULT	
DEVICE FRIENDLY ADDRESS NAME		AAAA	BBBB	2222	××××	





FIG. 12

CONDITION SETUP OBJECT : TERM	IINAL C ▼						
CONNECTION DETECTING CONDITIONS SETUP ITEMS	INQUIRY ISSUE NUMBER OF TIMES INTERVAL ms DETECTION NUMBER MAINTENANCE TIME ms						
INQUIRY DETECTION MODE O FIXED VARIABLE							
DISCONNECTION DETECTING CONDITIONS SETUP ITEMS <	CONNECTION REQUEST ISSUE NUMBER-OF-TIMES NUMBER-OF-TIMES INTERVAL ms DETECTION NUMBER MAINTENANCE TIME ms						
CONNECTION REQUEST DETECTION MODE O FIXED VARIABLE							
	REGISTER CANCEL						